




The **LOUD** Speaker Company®

## WALL/CEILING MOUNT



## FOR CVE-SERIES SPEAKERS

Read all operating instructions and safety information in this manual before using the accessory.

Failure to follow these safety instructions could result in personal injury or damage to the speaker or other property.

**Contents**

IMPORTANT SAFETY INSTRUCTIONS..... 3

Introduction ..... 4

Example Use..... 5

Supplied Parts and Hardware ..... 6

Mounting Instructions ..... 7

Warranty ..... 14

How to Obtain Warranty Service ..... 16

## IMPORTANT SAFETY INSTRUCTIONS

All warnings should be read and followed.

Retain this user manual for future reference.


**It is essential that this accessory is firmly secured to the wall/ceiling. Consult a qualified source for selection of proper installation fasteners. It is the user's responsibility to ensure that this accessory is installed securely.**

**Cerwin-Vega cannot be held responsible for damage caused by improper use of this accessory.**


## Introduction

Congratulations! Welcome to the Cerwin-Vega family! You've joined a growing group of audio professionals who have turned to Cerwin-Vega for the most advanced audio reproduction systems available. All Cerwin-Vega products are thoroughly tested to ensure that they meet or exceed our performance specifications. Backed by the best service in the industry, Cerwin-Vega is dedicated to quality and reliability. For a complete overview of Cerwin-Vega products and services, visit [www.cerwin-vega.com](http://www.cerwin-vega.com)


The wall/ceiling mount for CVE-series speakers was designed to allow installation of a CVE-10, CVE-12, or CVE-15 on a wall or ceiling. It allows the speaker angle to be adjusted 90° from center in either direction in 22.5° increments.



## Example Use









Ceiling Mount



Wall Mount


## Supplied Parts and Hardware

Before starting assembly, please inspect the contents to confirm that all of the items below are included and undamaged. If any parts are missing or damaged, contact Gibson Customer Service. Never use damaged parts.




## Mounting Instructions

**Step 1** – Remove the handles on the back of the speaker by using a 4mm hex wrench to loosen the screws. (Note: the CVE-10 does not have an upper handle; instead, remove the Cerwin-Vega plate as shown below.)




CVE-12 and CVE-15



CVE-10


## Mounting Instructions (continued)

**Step 2** – Using the screws from Step 1, secure the Speaker Brackets (3) to the locations from which the handles were removed.



## Mounting Instructions (continued)



**Step 3** – Use the screws (4), washers (5), and nuts (6) to secure the Upper U-Channel (1) and Lower U-Channel (2) together. Make sure that the pieces are assembled in the position that fits your speaker.



## Mounting Instructions (continued)


**Step 4** – Drill holes in the wall or ceiling according to the hole pattern below. Install the U-channels using screws/anchors suitable for your installation.

**It is essential that this accessory is firmly secured to the wall/ceiling. Consult a qualified source for selection of proper installation fasteners. It is the user's responsibility to ensure that this accessory is installed securely.**




## Mounting Instructions (continued)

**Step 5** – Secure the speaker onto the U-channels by installing the Thumbscrews (7) through the top and bottom Speaker Brackets.




## Mounting Instructions (continued)

**Step 6** – Install a Thumbscrew (7) through each of the Speaker Brackets to secure the speaker at the desired angle.



## Mounting Instructions (continued)

**Step 7** – It is recommended to use safety cables to attach the speaker to the mounting bracket. Safety cables can be attached to the extra holes in the U-channels and unused holes in the Speaker Brackets.



## Warranty

Thank you for choosing one of Gibson Pro Audio's brands (Stanton, KRK, or Cerwin-Vega).

Your satisfaction is extremely important to us. We proudly stand behind the quality of our work and appreciate that you put your trust in us. Registering your merchandise will help us guarantee that you are kept up to date on our latest advances.

To Register Merchandise Purchased from an Authorized Gibson Pro Audio Dealer in the U.S.:

Please go to: <http://www.gibson.com> and register online.

Or you may send your warranty card to:

Gibson Customer Service

309 Plus Park Blvd.

Nashville, TN 37217

If you have any questions you may contact customer service at:

1-800-4GIBSON (1-800-444-2766)

e-mail: [service@gibson.com](mailto:service@gibson.com)

FOR MERCHANDISE PURCHASED FROM AN AUTHORIZED GIBSON PRO AUDIO DISTRIBUTOR OUTSIDE OF THE US, PLEASE CONTACT THE DISTRIBUTOR FROM WHOM YOU PURCHASED YOUR MERCHANDISE FOR TO REGISTER YOUR WARRANTY AND FOR HANDLING AND RESOLUTION OF ALL WARRANTY-RELATED ISSUES.

### Gibson Pro Audio Warranty

If at any time your Gibson Pro Audio product (which includes Stanton, KRK, or Cerwin-Vega brands) malfunctions as a result of faulty materials or workmanship, Gibson Pro Audio or one of Gibson Pro Audio's Authorized Service Centers in the US will repair the defect(s) or replace the merchandise as it deems appropriate at its sole discretion.

Warranty Period (from date of Purchase as listed on the Bill of Sale):

#### Stanton

One (1) year for all Stanton products

#### KRK

Three (3) years for all studio monitors

One (1) year for all headphones and computer audio devices, including room-correction devices

#### Cerwin-Vega

Five (5) years for all passive speaker systems

Three (3) years for all active speaker systems

Three (3) years for all mixers

Gibson will warrant all replacement parts and repairs for ninety (90) days from the date of original shipment.

In the unlikely event that your merchandise is destroyed, lost, or damaged beyond repair while in the possession of Gibson or one of Gibson Pro Audio's Authorized Service Centers for repair, Gibson will replace that merchandise with one of the same or most similar style of a value not more than the original purchase price of your merchandise. Any insurance covering the merchandise, including but not limited to collector's value insurance, must be carried by the owner at the owner's expense.

For the fastest and safest merchandise return, please use the original shipping carton and packaging materials. Gibson cannot be responsible for any damages incurred during the shipping process due to poor or inadequate packing.

THIS WARRANTY IS EXTENDED TO THE ORIGINAL RETAIL PURCHASER ONLY AND MAY NOT BE TRANSFERRED OR ASSIGNED TO SUBSEQUENT OWNERS. TO VALIDATE YOUR WARRANTY, AND AS A CONDITION PRECEDENT TO WARRANTY COVERAGE HEREUNDER, YOU MUST REGISTER YOUR WARRANTY WITHIN FIFTEEN (15) DAYS FOLLOWING THE ORIGINAL DATE OF PURCHASE. YOUR PROOF OF PURCHASE OR SALES RECEIPT MUST ACCOMPANY ALL REQUESTS FOR WARRANTY COVERAGE.

This warranty is subject to the following limitations:

THIS WARRANTY DOES NOT COVER

1. Any merchandise that has been altered or modified in any way or upon which the serial number has been tampered with or altered.
2. Any merchandise whose warranty card has been altered or upon which false information has been given.
3. Any merchandise that has been damaged due to misuse, negligence, or improper operation.
4. Any merchandise that has been damaged by accident, flood, fire, lightning, or other acts of nature.
5. Shipping damage of any kind.
6. Any merchandise that has been subjected to extremes of humidity or temperature.
7. Any merchandise that has been purchased from an unauthorized dealer, or upon which unauthorized repair or service has been performed.

GIBSON MAKES NO OTHER EXPRESS WARRANTY OF ANY KIND WHATSOEVER. ALL IMPLIED WARRANTIES, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, EXCEEDING THE SPECIFIC PROVISIONS OF THIS WARRANTY ARE HEREBY DISCLAIMED AND EXCLUDED FROM THIS WARRANTY. SOME STATES AND/OR COUNTRIES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF IMPLIED WARRANTIES SO THAT THE ABOVE MAY NOT APPLY TO YOU.

GIBSON SHALL NOT BE LIABLE FOR ANY SPECIAL, INDIRECT CONSEQUENTIAL, INCIDENTAL OR OTHER SIMILAR DAMAGES SUFFERED BY THE PURCHASER OR ANY THIRD PARTY, INCLUDING WITHOUT LIMITATION, DAMAGES FOR LOSS OF PROFITS OR BUSINESS OR DAMAGES RESULTING FROM USE OR PERFORMANCE OF THE MERCHANDISE, WHETHER IN CONTRACT OR IN TORT, EVEN IF GIBSON OR ITS AUTHORIZED REPRESENTATIVE HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, AND GIBSON SHALL NOT BE LIABLE FOR ANY EXPENSES, CLAIMS, OR SUITS ARISING OUT OF OR RELATING TO ANY OF THE FOREGOING.

FOR MERCHANDISE PURCHASED FROM AN AUTHORIZED GIBSON PRO AUDIO DISTRIBUTOR OUTSIDE OF THE US, PLEASE CONTACT THE DISTRIBUTOR FROM WHOM YOU PURCHASED YOUR MERCHANDISE FOR THE HANDLING AND RESOLUTION OF ALL WARRANTY ISSUES. FOR THESE PURCHASES, THE ABOVE-DESCRIBED WARRANTY IS NOT APPLICABLE.

## How to Obtain Warranty Service

### Warranty service outside the United States

To initiate a warranty repair, please contact the Authorized Gibson Pro Audio distributor from whom you purchased your merchandise and follow the distributor's return/warranty policy.

### Warranty service for merchandise purchased from an authorized Gibson Pro Audio dealer in the U.S.

In the event of malfunction of your Gibson Pro Audio merchandise, the Dealer or Owner must call Customer Service at 1-800-4GIBSON (1-800-444-2766), and obtain a Return Authorization number from the customer service agent. No merchandise may be returned to Gibson without such prior Return Authorization, and the Return Authorization number must be written on the outside of the shipping package. The Customer Service agent will provide the address and additional shipping instructions. The owner must ship the merchandise with freight and insurance pre-paid to the address provided by the customer service representative. Only Authorized Gibson Pro Audio Service Centers may perform warranty service; any service performed by unauthorized persons will void this warranty. Gibson disclaims liability for defects or damage caused by services performed by unauthorized persons or non-warranty service not performed by Gibson or an Authorized Gibson Pro Audio Service Center.

When contacting Gibson, you must include a complete written description of the malfunction of the merchandise. If non-warranty work is required or recommended, a quotation will be issued that must be approved by you before any non-warranty work is commenced. You should consider quotations obtained for non-warranty work immediately and advise the Authorized Gibson Pro Audio Service Center or Gibson of your decision. You are not required to purchase non-warranty work in order to obtain service on materials covered by this warranty. Following its inspection of merchandise upon its arrival, Gibson or the Authorized Gibson Pro Audio Service Center will advise you or your dealer of the approximate date of completion. The repaired merchandise or part will be returned to you or your dealer, freight collect insured.

No representative or other person is authorized to assume for Gibson any liability except as stated in this warranty. This warranty gives you specific rights which vary from state to state and country to country.

For further information, write

Customer Service Dept.,  
Gibson Customer Service  
309 Plus Park Blvd.  
Nashville, TN 37217

Or call

1-800-4GIBSON (1-800-444-2766)